



WHE00026.203
ORANGE



WHE00026.210
BLACK



WHE00026.221
YELLOW FLUO

Technical Details

ZENITH HI VIZ HELMET

EXTERNAL SHELL: ABS

INTERNAL SHELL: HD Expanded polystyrene


HEADBAND: Soft PA Nylon

SIZE: Universal-adjustable from 53 to 63 cm

STANDARD: ANSI Z89.1-2014 / CSA Z94.1-2015

EN 12492 Shock Absorbing Capacity (clauses 4.2.1.2; 4.2.1.3; 4.2.1.4)

TYPE 1 CLASS E

 430 g / 0.92 lb
(without accessories)



CSA: -30°C / +50°C
-22°F / +122°F
ANSI: -18°C / +49°C
0°F / +120°F

SC2 EARMUFFS

Attachment to the helmet with a bayonet adapter

Universal 30 mm euro slot

Smooth telescopic size regulation

Non-conductive

Certified for use with KASK helmet

 271 g **NRR** >26-30 dB (A)

ZEN MESH VISOR

MATERIAL: Metal

STANDARD: EN 1731/ANSI Z87.1

LIGHT TRANSMISSION: 50%

 100 g

Technology



ELECTRIC SHOCK
PROTECTION

PROTECTION AGAINST ELECTRIC SHOCK: Helmet provides protection against electrical hazards for use in the vicinity of low voltage systems with voltages up to 20.000 V.



FLUO

FLUORESCENT SHELL: High visibility fluorescent color shell. Available in yellow fluo, white fluo, red fluo and lime fluo. The intensity of the luminescence color may decrease in time.



LUMINESCENT

LUMINESCENT CLIPS: Helmet is equipped with strong external luminescent carrying clips, compatible with all headlamps with elastic bands on the market.



ECO

ECO LEATHER CHINSTRAP: Eco-leather, hypoallergenic, washable chinstrap which is extremely comfortable and helps avoid irritation of the skin.



REFLECTIVE

REFLECTING STICKERS: Adhesive reflective stickers for high visibility.



RING TO HOOK

RING TO HOOK: Fitted with a special hook on the chinstrap which allows the helmet to be connected to the harness.



SANITIZED®

SANITIZED®: The Sanitized® treatment is an antibacterial treatment that acts as an internal deodorant counteracting the development of unpleasant odors. Thanks to its hygienic function, it effectively prevents bacterial proliferation by increasing comfort of the fabric in contact with skin.



FAST3DRY

FAST 3DRY: High-tech 3D fabric that dries very quickly, helping the dispersion of moisture to the outside and leaving a pleasant feeling.



UP&DOWN 2.0

UP & DOWN 2.0: The innovative and exclusive UP & Down 2.0 technology ensures a precise and comfortable fit around the back of the head. The center wheel and the two side wings allow the quick adjustment of the helmet not only in width but also in height and tilt.



VISOR

VISOR ATTACHMENT: Provided with attachment for fitting Zenith visors.



EARMUFFS

EARMUFFS FITTING: Built with integrated slot for earmuffs. Compatible with KASK earmuffs.

SC2 Earmuffs technology

The yellow SC2 earmuffs are suitable for environments with a medium to high level of noise (dB). The best choice in high frequency noise situations. Suitable for a wide variety of uses such as: building and construction, forestry use, industrial areas, production areas, agriculture, ecc.



YELLOW - WHP00001.202

SECURE 2C, ANSI S-3.19 - 1974, NRR-24, CSA A

Frequency Hz	125	250	500	1000	2000	3150	4000	6300	8000
Mean Attenuation	15,7	20,7	28,8	36,9	35,2	37,0	37,8	39,6	38,6
Std. dev	2,8	2,1	3,0	2,9	3,2	3,4	2,2	2,4	2,8

Zen Mesh Visor technology

The metal visor, consisting in a special hexagonal weave, guarantees higher transparency for major security also in low visibility conditions. The visor protects against dust particles and abrasion and is placed close to the face for superior protection. The inner air flow guarantees an active micro-ventilation and gives a pleasant feeling of comfort. Also ideal for overlapping corrective glasses. Compatible with models: Zenith; Zenith BA, Zenith BA AIR, Zenith PL

Additional Information



GUARANTEE

3 years starting from the purchasing date.

SHELF LIFE

10 years starting from the production date (production date is printed on a label contained on the inside of the helmet). Inspect the helmet regularly to check for any damage! Cuts, abrasions, deformation or changes in colour represent important elements for checking the helmet status.

CLEANING

Clean the helmet only with water, neutral pH soap and a soft, clean cloth. The inner lining should be washed by hand in cold water or in the washing machine (max 30°C - 85°F). Do not use chemical detergent or solvent.

STORAGE

When not in use the helmet should be stored away from direct sunlight or source of heat.

ADHESIVE APPLICATION

Do not apply adhesives, solvents, stickers or paint that do not comply with the manufacturer's specifications. Any alteration or intervention not provided for may impair its protective function.

Accessories



WV100007
ZEN VISOR



WV100012
ZEN FULL FACE



WPA00006
REPLACEMENT INNER PADDING



UPA00001
WINTER PADDING



UAC00002
HELMET BAG